



# User's Manual

# Index

- **Game Description** ..... P.01
- **Operating Instructions** ..... P.03
- **System Adjustment** ..... P.04
- **Cable Definition** ..... P.06
- **Report & Reset** ..... P.07

## CAUTION

The first time you start the system, it will display a full black screen.  
Press "ENTER" to enter password( default : 00000000 ).  
After that, enter the process of Game Authorization(ปลดล็อกเกม).

# Game Description

## ★【Game play instructions】

《Sushi 2020》 Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 2 / 3 / 4 / 6 / 8 / 10 while online games. 21 different types of fish, 11 kinds of powerful special weapons, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

## ★【Game Features Description】

### ▶ Special item — Floating in the field. Attack them to release special power!!

- ◆ สายไฟ→ Attacking fishes in the field continuously.
- ◆ระเบิดปลาหมึก→ Killing it drop a bomb cause octopus get mad and fooling around. Press attack button cause bomb explode .
- ◆ระเบิดใหญ่→ Killing inflated red octopus explode the Devastating Bomb. kill all fish in the field. (excluding special fishes).
- ◆เรือไวกิ้ง→ Attack the Viking Ship has a chance to drop random treasure . Success break it will win high score award.
- ◆เทพร่ำรวย→ Press the attack button to shock the treasure bowl. The God of Wealth will randomly send rewards.
- ◆เต่าภูเขาไฟ→ Hit the Volcanic Beast may fall one rock with attack effect. Defeat the Volcanic Beast will get x200 reward & lead full-screen rock attack.

### ▶ Special Fish

- ◆ปลานำโชค→ When killing the lucky fish, player will get a x2~x10 Bonus reward for any kind of fish.
- ◆มังกรไฟ→ Get a x200~x800 Bonus reward.
- ◆การ์ดโชคดี→ Scrape out 3 identical prizes, win the prize. There have 3 chances to win.

# Game Description

## ★ [Odds Table]

			
x2	x3	x4	x4
			
x5	x5	x8	x8
			
x10	x10	x12	x15
			
x18	x20	x25	x30
			
x40	x50	x100	x200
			
x400			



# Operating Instructions

## ★【Operation Panel Instruction】



## ★【Basic Operations】

- ▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

### ! CAUTION

- ◆ **Auto Attack** → Press the "Shoot Button" 3 seconds to launch.
- ◆ **Aim Attack** → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

## ★【Play skills】

- ▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster. If you are lucky, get the biggest 400 bet fish multiply 10 times is not just dreaming.

# System Adjustment

## ★ 【ตั้งค่าระบบ/เกม—ตั้งค่าที่ดู】

Item	Default	Parameters
จำนวนขั้นต่ำในการแทง	10	1, 2, 5, 10, 20, 30, 40, 50, 100, 200, 250
จำนวนสูงสุดในการแทง	1000	10, 20, 30, 40, 50, 100, 200, 500, 1000
อัตราการเพิ่มการเดิมพัน	10	1, 2, 5, 10, 20, 50, 100, 200, 500, 1000
จำกัดการเพิ่มเครดิต	1000000	5000, 6000, 10000, 15000, 20000, 30000, 50000, 100000, 150000, 200000, 500000, 1000000, 2000000, 5000000, 10000000, 20000000, 50000000, 90000000
จำกัดจำนวนกำไรของลูกค้ำ	5000000	10000, 15000, 20000, 30000, 40000, 50000, 100000, 150000, 200000, 300000, 500000, 1000000, 2000000, 5000000, 10000000, 20000000, 50000000, 90000000
ตัวรางวัล	1	1/100, 1/80, 1/50, 1/25, 1/15, 1/10, 1/8, 1/5, 1/4, 1/3, 1/2, 1, 2, 3, 4, 5, 8, 10, 15, 20, 25, 50, 80, 100
โหมดเกม	กดปุ่มออกเหรียญ	กดปุ่มออกเหรียญ, กดปุ่มออกตัว, ออกตัวระหว่างเกมส์, ออกเหรียญระหว่างเกมส์, ออกเหรียญ, ออกตัว, ล้างคะแนนอย่างด่วน
ความเร็วในการยิง	ปานกลาง	ช้า, ปานกลาง, เร็ว
ความเร็วของกระสุน	ปานกลาง	ช้า, ปานกลาง, เร็ว
ยิงอัตโนมัติ(ลูกค้ำนั่งแช่)	ไม่มี	ไม่มี, ช้า, ปานกลาง, เร็ว
ยิงอัตโนมัติ	เปิด	ปิด, เปิด
LOCK	เปิด	ปิด, เปิด
จำนวนผู้เล่น	8(3-1)	2(2-0), 3(3-0), 4(2-2), 4(4-0), 6(2-1), 6(3-0), 8(2-2), 8(3-1), 8(4-0), 10(3-2), 10(4-1)
เปิด-ปิดเสียง	เปิด	ปิด, เปิด, ประสิทธิภาพเสียง, ดนตรี
ปรับระดับเสียง	4	0, 1, 2, 3, 4, 5, 6, 7, 8

# System Adjustment

## ★ [ตั้งค่าระบบ/เกม—ตั้งค่าโดยใช้รีโมท]

Item	Default	Parameters
1เหรียญก็เครดิต	100	1 , 2 , 5 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000
กดยุแเข้า1ครั้งก็เครดิต	1000	100 , 200 , 250 , 500 , 1000 , 2000 , 2500 , 5000 , 10000 , 20000 , 25000 , 50000 , 100000
ระดับความยาก	5	0 , 1 , 2 , 3 , 4 , 5
ขนาดร้าน	สถานที่ ขนาดกลาง	สถานที่ขนาดเล็ก, สถานที่ขนาดกลาง, สถานที่ ขนาดใหญ่
โอกาสได้คะแนนพิเศษ	ระดับกลาง	ปิด, ระดับต่ำ, ระดับกลาง, ระดับสูง
ตั้งเวลาแจ้งยอด	10	1 ~ 30
ตั้งจำนวนเครดิตแจ้งยอด	100000	10000 ~ 300000
เวลาเครื่อง	-	
แก้ไขรหัสผ่าน	-	



Total record (เช็คยอดรวม) default password :  
「 0000 0000 」

# Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

# Report & Reset

- ▶ Press “Enter” to enter the “System Operation(ฟังก์ชันระบบ)” menu.
- ▶ Select “Report(แจ้งยอด)” or “Reset(ล้างยอด)” , enter the page.
- ▶ Report the information on the page to your agent to get the Digit Code.
- ▶ Enter the reported Digit Code and press the “\*” .
- ▶ The screen displays "Password Correct(รหัสผ่านถูกต้อง)", complete the “Report” or “Reset” process .

## ! CAUTION

The data of “Total Revenue(ยอดขายรวม)” and “ Current Revenue (ยอดขายปัจจุบัน)” in the “Reset” page is generated Instantly. **Don't return to the game state before complete the “Reset” process .** That will lead to changes in the data, the reported Digit Code can not be used.





# Note



# Note

