# FLYING HORSE

# User's Manual

# Index

# Game Description

★【Game play instructions】

《FLYING HORSE》Based on the bird ecology theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of birds, 13 kinds of powerful special Items, a clear definition and detailed outdoor scene. It's the most popular game machine in your Game center.

★【Game Features Description】

► Special Item—Floating in the field. Attack them to release special power!!

- ◆ Phoenix Flame➜          Powerful Phoenix Flame for free.
- ◆ Sky-Quake Drum➜         Sonic attack the birds near the Sky-Quake Drum.
- ◆ Wooden Mechanical Kite➜ Kill all normal birds in the field at once.
- ◆ Needle King➜            Launch powerful needle missiles attacking.
- ◆ Monkey King➜            Attack many times in small area.
- ◆ Flame Dragon➜           Summon Flame Dragon to attack bird.
- ◆ Flying Horse➜           Trigger a meteor shower to attack the bird on screen.
- ◆ Magic Gourd➜            Huge whirlwind will attack birds.

► Special Bird

- ◆ Flame Dragon ➜          Summon Flame dragon to attack bird.
- ◆ Flying Horse ➜          Trigger a meteor shower to attack the bird on screen.
- ◆ Magic Gourd➜            Huge whirlwind will attack birds .
- ◆ Bird King ➜             Kill all same kind birds in the field.
- ◆ Colorful Phoenix➜       Attack the Colorful Phoenix has a chance to drop a feather. Success defeat it will win a high score award.
- ◆ Smash The Golden Egg➜   Collect 5 feathers drop form the Colorful Phoenix .
- ◆ Lucky Bird➜             Kill any normal bird has a chance to become Lucky Bird, and get 2 to 10 times scores.
- ◆ Destiny Wheel➜          Play Destiny Wheel game.

01

# Game Description

| | | |
|---|---|---|
| x2 | x2 | x3 |
| x5 | x6 | x7 |
| x8 | x9 | x10 |
| x12 | x15 | x18 |
| x20 | x25 | x30 |
| x40 | x60 | x80 |
| X100~200 | X200~500 | X800~1200 |

# Operating Instructions

《 Direction Controller 》    《Shoot》    《Raise Bet 》

## ☆【Basic Operations 】

▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

**! CAUTION**

◆ Auto Attack➡Press the "Shoot Button" 3 seconds to launch.
◆ Aim Attack ➡Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select bird to aim.

## ☆【Play skills 】

▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at birds cluster.

# System Adjustment

| Item | Default | Parameters |
|---|---|---|
| Minimum Bet | 50 | 1~10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000 |
| Maximum Bet | 1000 | 1~10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000 |
| Bet Increase rate | 10 | 1~10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000 |
| Credit Limit | 1000000 | 5000 , 6000 , 10000 , 15000 , 20000 , 30000 , 50000 , 100000 , 150000 , 200000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000 |
| System Limit | 2000000 | 10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000 |
| Ticket Ratio | 1 | 1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/8 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100 |
| Withdraw Mode | Key Out (Coin) | Key Out(Coin)、Key Out(Ticket)、Coin out in game、Ticket out in game、Key Out (Print Voucher) |
| Shooting Speed | Medium | Slow、Medium、Fast |
| Bullet Speed | Medium | Slow、Medium、Fast |
| AutoTrigge Time | No | No、Slow、Medium、Fast |
| Auto shoot | On | Off、On |
| LOCK | On | Off、On |
| Player Steering | Standard | Inverse、Standard |
| Station Quantity | 8(3-1) | 2(2-0) , 3(3-0) , 4(2-2) , 4(4-0) , 6(2-1) , 6(3-0) , 8(2-2) , 8(3-1) , 8(4-0) , 10(3-2) , 10(4-1) |
| BGM | On | Off、On、SE、BGM |
| Volume | 4 | 0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 |

# System Adjustment

| Item | Default | Parameters |
|---|---|---|
| Coin Ratio | 100 | 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000 |
| Key In Ratio | 1000 | 100 , 200 , 250 , 500 , 1000 , 2000 , 2500 , 5000 , 10000 , 20000 , 25000 , 50000 , 100000 |
| Game Difficulty | 6 | 0 ~ 20 |
| Location Scale | Medium Location | Small Location、Medium Location、Large Location |
| Bonus odds rate | Mid | Low , Mid , High |
| Report Time period | 10 | 0 ~ 30 |
| Profit Limit to Report | 100000 | 0 , 10000 , 20000 , …… , 300000 |
| System Time | -- | YYYY/MM/DD HH:MM:SS |
| Change Password | 00000000 | |

**! CAUTION**

Total record default password ： 『0000 0000』

# Cable Definition

| | | | |
|---|---|---|---|
| Up | 1 | 2 | Down |
| Left | 3 | 4 | Right |
| Raise bet | 5 | 6 | Shoot |
| Coin in | 7 | 8 | Key in |
| Key out | 9 | 10 | Pay out |
| Ticket SW | 11 | 12 | Hopper SW |
| Ticket SSR | 13 | 14 | Hopper SSR |
| Shoot lamp | 15 | 16 | Raise bet lamp |
| +12V | 17 | 18 | +12V |
| +12V | 19 | 20 | +12V |
| +5V | 21 | 22 | Ground |
| Ground | 23 | 24 | Ground |
| Ground | 25 | 26 | Ground |

# Report & Reset

▶ Press "Enter" to enter the "System Operation" menu.
▶ Select "Report" or "Reset", enter the page.



```
                    2017/06/29 18:25:45     M100FA
[ Reset ]
        Total Profit              505
        Current Profit            505

        Game Serial No.          1991
        Machine No.          00000000
        Verification Code    64005227
        Reset Times                00


        Enter 16 Digit Code  0000-0000-0000-0000



[0~9] Enter Digit      [*] Confirm      [Enter] Exit
```

▶ Report the information on the page to your agent to get the Digit Code.
▶ Enter the reported Digit Code and press the "*".
▶ The screen displays "Password Correct", complete the "Report" or "Reset" process.

⚠ **CAUTION**

The data of "Total Profit" and "Current Profit" in the "Reset" page is generated Instantly. Don't return to the game state before complete the "Reset" process. That will lead to changes in the data, the reported Digit Code can not be used.

# Troubleshooting

1. VGAME's product wire accessories are specially made, and are different from commercially available accessories. Please use the shipped accessories.

2. Our accessories are different from accessories provided by other developers. Please refer to the layout picture as follow.

3. The control board's voltage must be simultaneously 12V and 5V. Please insert right to left from outside.

4. Please don't often clear current profits and move it over to total profit so as to affect the manner the games pays out.

## ☆Wrong decision

| Message | Solution |
|---------|----------|
| Boot appear no picture on screen | Reinserting IC (ROM) for checking may solve the problem.<br>If it is still defective, please contact us.  |
| Please Report Your Records 【1】 | Please report your records with the coder. |
| Appearing the report your records page continuously | If the system's time is error on the backstage, you can replace the lithium battery on the board. |

# Troubleshooting

| Message | Solution |
|---|---|
|  | (You also can check the report time period whether it depends on the operator setting) If it's still defective, please contact us. |
| Please Report Your Records 【2】 | Please reset with the coder. (If you adjust the Coin Ratio, then you will key in number with the coder. Finally, you reset with the coder.) |
| Please Report Your Records 【3】 | If it's still defective, please contact us. Then, tell us what appears on the screen. |
| Please Report Your Records 【4】 | If it's still defective, please contact us. Then, tell us what appears on the screen. |
| Appearing "999" on the game screeen | If it's still defective, please contact us. Then, tell us what appears on the screen. |
| Linked line error on the screen | Make sure the control Board's voltage is set on 12V and 5V at the same time, then check the Communication line.  |

# Troubleshooting

| Message | Solution |
|---|---|
| Error on the same seat | Make sure the control Board's voltage is set on 12V and 5V at the same time, then check the communicated line is normal. By the way, please also check the Du Pont line (Rainbow line) is normal or not. |
| Error on the different seat | Testing the Du Pont line (Rainbow line) on the each seats. If the different seats are broken, please check the Du Pont line and Button. |
| Unable to play on the all seats | Make sure the communication line is normal. |
| Coin Out error | Make sure the cash box are empty or not. Then, check solving the problem successfully. |
| Unable to Coin Out | Please don't set the zero on the Coin Ratio. |
| COIN LIMIT | The system notice unable to key in, but it can keep on playing the game. |
| SYSTEM LIMIT | If it can't play successfully, please press the "Key out" on the seat. Then, check solve the problem. |

# Troubleshooting

| Message | Solution |
|---------|----------|
| The game screen in unstable, appearing the faulty line. | Please check the Communication line and Cabinet. |

⚠ **CAUTION**

If the control Board and accessories are defective, please try another VGAME's mother board.

# NOTE

202111220 F500L20