

User's Manual

Game Description P.01 Operating Instructions P.03 System adjustment P.04 Cable definition P.06

Index

Game Description

☆【Game play instructions】

《BIRD's PARADISE USA》 Based on the bird ecology theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of birds, 10 kinds of powerful special Items, a clear definition and detailed outdoor scene. It's the most popular game machine in your Game center.

☆[Game Features Description]

Special Item—Floating in the field. Attack them to release special power!!


♦ Phoenix Flame→	Randomly upgrade normal bullet to powerful Phoenix Flame for free.
♦ Sky-Quake Drum→	Sonic attack the birds near the Sky-Quake
• Wooden Mechanical Kite-	 Drum. Wooden Mechanical Kites assault all normal birds in the field at once.
Special Bird	
♦ Bird King →	The bird with whirlwind. Kill all same kind birds
◆ Colorful Phoenix→	in the field. Attack the Colorful Phoenix has a chance to drop a feather. Success defeat it will win a high
◆ Smash The Golden Egg→	score award. Collect 5 feathers drop form the Colorful Phoe- nix will launch the bonus game.
◆ Lucky Bird→	Kill any normal bird has a chance to become Lucky Bird, and get 2 to 10 times scores.
🔶 Gold Eagle 🔿	Get x200~500 randomly.
🔶 Gold Peacock 🔿	Get x100~200 randomly.



Game Description

☆[Odds Table]

02





☆[Operation Panel Instruction]



☆ 【Basic Operations 】

It' s easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

CAUTION

- ◆ Auto Attack→Press the "Shoot Button" 3 seconds to launch.
- ◆ Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select bird to aim.

🛠 [Play skills]

Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at birds cluster.



System Adjustment

☆ [Parameter Adjust-Direct Adjust]


ltem	Default	Parameters				
Minimum Bet	50	1 , 2 , 5 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 250				
Maximum Bet	1000	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 ,10 , 20 , 30 , 40 , 50 , 100 , 200 , 500 , 1000				
Bet Increase rate	10	1 , 2 , 5 , 10 , 20 , 50 , 100 , 200 , 500 , 1000				
Credit Limit	1000000	5000, 6000, 10000, 15000, 20000, 30000, 50000, 100000, 150000, 200000, 500000, 1000000, 2000000, 5000000, 10000000, 20000000, 50000000, 90000000				
System Limit	2000000	10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000				
Ticket Ratio	1	1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/8 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100				
Withdraw Mode	Key Out (Coin)	Key Out(Coin) 、Key Out(Ticket) 、Coin out in game 、Ticket out in game				
Shooting Speed	Medium	Slow Medium Fast				
Bullet Speed	Medium	Slow Medium Fast				
AutoTrigge Time	No	No Slow Medium Fast				
Auto shoot	On	Off、On				
Station Quantity	8(3-1)	2(2-0) , $3(3-0)$, $4(2-2)$, $4(4-0)$, 6(2-1) , $6(3-0)$, $8(2-2)$, $8(3-1)$, 8(4-0) , $10(3-2)$, $10(4-1)$				
BGM	On	Off On SE BGM				
Volume	4	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8				



System Adjustment

☆ [Parameter Adjust-Report Adjust]

ltem	Default	Parameters			
Coin Ratio	100	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000			
Key In Ratio	1000	100 , 200 , 250 , 500 , 1000 , 2000 , 2500 , 5000 , 10000 , 20000 , 25000 , 50000 , 100000			
Game Difficulty	3	0 , 1 , 2 , 3 , 4 ,5			
Location Scale	Medium Location	Small Location、Medium Location、Large Location			
Bonus odds rate	Mid	Low , Mid , High			
Report Time period	10	0 ~ 30			
Profit Limit to Report	100000	0 , 10000 , 20000 , , 300000			
System Time		YYYY/MM/DD HH:MM:SS			
Change Pass- word	0000000				





Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

















20180712 V102FA