

User's Manual

Index

| Game Description | ·····P.01 |
|--|-----------|
| Operating Instructions | ····P.03 |
| System adjustment | ····P.04 |
| Cable definition · · · · · · · · · · · · · · · · · · · | ·····P.06 |

Game Description

☆ [Game play instructions]

«Holy Beasts of China» Based on the bird ecology theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of birds, 10 kinds of powerful special Items, a clear definition and detailed outdoor scene. It's the most popular game machine in your Game center.

☆ [Game Features Description]

▶ Special Item—Floating in the field. Attack them to release special power!!

◆ Phoenix Flame → Randomly upgrade normal bullet to powerful

Phoenix Flame for free.

♦ Sky-Quake Drum→ Sonic attack the birds near the Sky-Quake Drum.

♦ Wooden Mechanical Kite→ Wooden Mechanical Kites assault all normal

birds in the field at once.

♦ Holy Beasts → Get the holy beasts reward, or summon the yel-

low dragon to defeat all normal Species.

Special Bird

♦ Bird King → The bird with whirlwind. Kill all same kind birds

in the field.

◆ Colorful Phoenix→ Attack the Colorful Phoenix has a chance to

drop a feather. Success defeat it will win a high

score award.

◆ Smash The Golden Egg→ Collect 5 feathers drop form the Colorful Phoe-

nix will launch the bonus game.

◆ Lucky Bird → Kill any normal bird has a chance to become

Lucky Bird, and get 2 to 10 times scores.

◆ Gold Eagle → Get x200~500 randomly.

◆ Gold Peacock → Get x100~200 randomly.



Game Description

☆[Odds Table]

| \(\frac{1}{2}\) | | * |
|----------------------------|-----|-----|
| x2 | x2 | х3 |
| | | > |
| x5 | хб | x7 |
| | | |
| x8 | x9 | x10 |
| | | |
| x12 | x15 | x18 |
| | | |
| x20 | x25 | x30 |
| | | |
| x40 | x60 | x80 |

Operating Instructions

☆[Operation Panel Instruction]



☆ [Basic Operations]

▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

CAUTION

- ◆ Auto Attack→Press the "Shoot Button" 3 seconds to launch.
- ◆ Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select bird to aim.

☆ [Play skills]

▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at birds cluster.

System Adjustment

☆ [Parameter Adjust-Direct Adjust]

| ltem | Default | Parameters | | |
|-------------------|------------------|--|--|--|
| Minimum Bet | 50 | 1 , 2 , 5 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 250 | | |
| Maximum Bet | 1000 | 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 ,10 , 20 , 30 , 40 , 50 , 100 , 200 , 500 , 1000 | | |
| Bet Increase rate | 10 | 1 , 2 , 5 , 10 , 20 , 50 , 100 , 200 , 500 , 1000 | | |
| Credit Limit | 1000000 | 5000 , 6000 , 10000 , 15000 , 20000 , 30000 , 50000 , 100000 , 150000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000 | | |
| System Limit | 2000000 | 10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000 | | |
| Ticket Ratio | 1 | 1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/8 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100 | | |
| Withdraw Mode | Key Out | Key Out(Coin) \ Key Out(Ticket) \ Coin out in | | |
| Shooting Speed | (Coin) Medium | game \ Ticket out in game Slow \ Medium \ Fast | | |
| Bullet Speed | Medium | Slow \ Medium \ Fast | | |
| AutoTrigge Time | No | No · Slow · Medium · Fast | | |
| Auto shoot | On | Off • On | | |
| Station Quantity | 8(3-1) | 2(2-0) , 3(3-0) , 4(2-2) , 4(4-0) , 6(2-1) , 6(3-0) , 8(2-2) , 8(3-1) , 8(4-0) , 10(3-2) , 10(4-1) | | |
| BGM | On | Off \ On \ SE \ BGM | | |
| Volume | 4 | 0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 | | |

System Adjustment

☆ [Parameter Adjust-Report Adjust]

| ltem | Default | Parameters |
|---------------------------|--------------------|--|
| Coin Ratio | 100 | 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000 |
| Key In Ratio | 1000 | 100 , 200 , 250 , 500 , 1000 , 2000 , 2500 , 5000 , 10000 , 20000 , 25000 , 50000 , 100000 |
| Game Difficulty | 3 | 0 , 1 , 2 , 3 , 4 ,5 |
| Location Scale | Medium Location | Small Location、Medium Location、Large Location |
| Bonus odds rate | Mid | Low , Mid , High |
| Report Time period | 10 | 0 ~ 30 |
| Profit Limit to Report | 100000 | 0 , 10000 , 20000 , , 300000 |
| System Time | | YYYY/MM/DD HH:MM:SS |
| Change Password | 00000000 | |



Total record default password : 『 0000 0000 』

Cable Definition

| Up | 1 | 2 | Down |
|------------|----|----|----------------|
| Left | 3 | 4 | Right |
| Raise bet | 5 | 6 | Shoot |
| Coin in | 7 | 8 | Key in |
| Key out | 9 | 10 | Pay out |
| Ticket SW | 11 | 12 | Hopper SW |
| Ticket SSR | 13 | 14 | Hopper SSR |
| Shoot lamp | 15 | 16 | Raise bet lamp |
| +12V | 17 | 18 | +12V |
| +12V | 19 | 20 | +12V |
| +5V | 21 | 22 | Ground |
| Ground | 23 | 24 | Ground |
| Ground | 25 | 26 | Ground |







