



# User's Manual

20200914 V200E22

### Index

Game Description	····P.01
Operating Instructions	····P.03
• System adjustment	····P.04

• Cable definition ······P.06



09

### NOTE

### **Game Description**

#### ★ 【Game play instructions】

**《PEACOCK KING》** Based on the bird ecology theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of birds, 11 kinds of powerful special Items, a clear definition and detailed outdoor scene. It's the most popular game machine in your Game center.

☆ 【Game Features Description 】

♦ Gold Peacock →

- Special Item—Floating in the field. Attack them to release special power!!
- Phoenix Flame Randomly upgrade normal bullet to powerful Phoenix Flame for free. Sky-Quake Drum-Sonic attack the birds near the Sky-Quake Drum. Wooden Mechanical Kite-Wooden Mechanical Kites assault all normal birds in the field at once. ♦ Invincible Bomb→ Attack all birds in the field. ♦ Chain Lightning → Attack birds in the field continuously. Special Bird ♦ Bird King → The bird with whirlwind. Kill all same kind birds in the field. Attack the Phoenix has a chance to drop a ♦ Fire Phoenix→ feather. Success defeat it will win a high score award. ◆ Smash The Golden Egg→ Collect 5 feathers drop form the Colorful Phoenix will launch the bonus game. ◆ Peacock King → Shoot feathers to attack birds. ♦ Bird Fly → Keep pressing the button to make birds fly out. Kill any normal bird has a chance to become ◆ Lucky Bird→ Lucky Bird, and get 2 to 10 times scores. ♦ Gold Eagle → Get x200~500 randomly.




Get x100~200 randomly.

## **Game Description**

#### ☆ 【Odds Table】

02



## NOTE



### Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

## **Operating Instructions**

#### ★ 【 Operation Panel Instruction 】



#### 🖈 🕻 Basic Operations 🕽

It' s easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

#### CAUTION

- ◆ Auto Attack→Press the "Shoot Button" 3 seconds to launch.
- ◆ Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select bird to aim.

#### 🖈 🛛 Play skills 🕽

Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at birds cluster.





### System Adjustment

### ☆ [Parameter Adjust-Direct Adjust]

	2			
ltem	Default	Parameters		
Minimum Bet	50	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000		
Maximum Bet	1000	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000		
Bet Increase rate	10	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000		
Credit Limit	1000000	5000, 6000, 10000, 15000, 20000, 30000, 50000, 100000, 150000, 200000, 500000, 1000000, 2000000, 5000000, 10000000, 20000000, 50000000, 90000000		
System Limit	2000000	10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000		
Ticket Ratio	1	1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/8 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100		
Withdraw Mode	Key Out (Coin)	Key Out(Coin) < Key Out(Ticket) < Coin out in game < Ticket out in game		
Shooting Speed	Medium	Slow  Medium  Fast		
Bullet Speed	Medium	Slow    Medium    Fast		
AutoTrigge Time	No	No  Slow  Medium  Fast		
Auto shoot	On	Off   On		
Lock	On	Off  On		
Player Steering	Standard	Stabdard   Inverse		
Station Quantity	8(3-1)	2(2-0) , 3(3-0) , 4(2-2) , 4(4-0) , 6(2-1) , 6(3-0) , 8(2-2) , 8(3-1) , 8(4-0) , 10(3-2) , 10(4-1)		
BGM	On	Off   On  SE  BGM		
Volume	4	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8		

## System Adjustment

#### ☆ [Parameter Adjust-Report Adjust]

ltem	Default	Parameters
Coin Ratio	100	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000
Key In Ratio	1000	100 , 200 , 250 , 500 , 1000 , 2000 , 2500 , 5000 , 10000 , 20000 , 25000 , 50000 , 100000
Game Difficulty	6	0 ~ 20
Location Scale	Medium Location	Small Location、Medium Location、Large Location
Bonus odds rate	Mid	Low , Mid , High
Report Time period	10	0 ~ 30
Profit Limit to Report	100000	0 , 10000 , 20000 , , 300000
System Time		YYYY/MM/DD HH:MM:SS
Change Pass- word	0000000	

**CAUTION** Total record default password : **©** 0000 0000 **』** 

