

User's Manual

Game Description P.01 Operating Instructions P.03 System adjustment P.04 Cable definition P.06

Index

Game Description

☆【Game play instructions】

«Suck My Dick» Based on the bird ecology theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of birds, 10 kinds of powerful special Items, a clear definition and detailed outdoor scene. It's the most popular game machine in your Game center.

☆[Game Features Description]

Special Item—Floating in the field. Attack them to release special power!!


♦ Phoenix Flame→	Randomly upgrade normal bullet to powerful Phoenix Flame for free.
♦ Sky-Quake Drum→	Sonic attack the birds near the Sky-Quake
Wooden Mechanical Kite-	 Drum. Wooden Mechanical Kites assault all normal birds in the field at once.
Special Bird	
♦ Bird King →	The bird with whirlwind. Kill all same kind birds in the field.
◆ Colorful Phoenix→	Attack the Colorful Phoenix has a chance to drop a feather. Success defeat it will win a high
◆ Smash The Golden Egg→	score award. Collect 5 feathers drop form the Colorful Phoe- nix will launch the bonus game.
◆ Lucky Bird→	Kill any normal bird has a chance to become Lucky Bird, and get 2 to 10 times scores.
🔶 Gold Eagle 🔿	Get x200~500 randomly.
♦ Gold Peacock →	Get x100~200 randomly.



Game Description

☆[Odds Table]

02





☆[Operation Panel Instruction]



☆ 【Basic Operations 】

It' s easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

- ◆ Auto Attack→Press the "Shoot Button" 3 seconds to launch.
- ◆ Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select bird to aim.

🖈 [Play skills]

Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at birds cluster.



System Adjustment

☆ [Parameter Adjust-Direct Adjust]

ltem	Default	Parameters			
Minimum Bet	50	1 , 2 , 5 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 250			
Maximum Bet	1000	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 500 , 1000			
Bet Increase Rate	10	1 , 2 , 5 , 10 , 20 , 50 , 100 , 200 , 500 , 1000			
Credit Limit	1000000	5000, 6000, 10000, 15000, 20000, 30000, 50000, 100000, 150000, 200000, 500000, 1000000, 2000000, 5000000, 10000000, 20000000, 50000000, 90000000			
System Limit	2000000	10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000			
Ticket Ratio	1	1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/8 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100			
Withdraw Mode	Key Out (Coin)	Key Out(Coin) < Key Out(Ticket) < Coin out in game < Ticker out in game			
Shooting Speed	Medium	Slow • Medium • Fast			
Bullet Speed	Medium	Slow Medium Fast			
AutoTrigger Time	No	No 、Slow 、Medium 、Fast			
Auto shoot	On	Off、On			
Station Quantity	8(3-1)	2(2-0), 3(3-0), 4(2-2), 4(4-0), 6(2 -1), 6(3-0), 8(2-2), 8(3-1), 8(4- 0), 10(3-2), 10(4-1)			
BGM	On	Off On SE BGM			
Volume	4	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8			



System Adjustment

☆ [Parameter Adjust-Report Adjust]

ltem	Default	Parameters			
Coin Ratio	100	1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000			
Key In Ratio	1000	100 , 200 , 250, 500 , 1000 , 2000 , 2500, 5000, 10000 , 20000 , 25000, 50000,100000			
Game Difficulty	3	0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8 , 9 , 10			
Location Scale	Medium Location	Small Location、Medium Location、Large LocationLow Low , Mid , High			
Bonus odds rate	Mid	Low , Mid , High			
Report Time period	10	0 ~ 30			
Profit Limit to Report	100000	0 , 10000 , 20000 , , 300000			
System Time		YYYY/MM/DD HH:MM:SS			
Change Password	00000000				

CAUTION

Total record default password : 『 0000 0000 』



Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

















20180604 V204FA1