



User's Manual



Game Description ······	·P.01
Operating Instructions ······	·P.03
System Adjustment	·P.04
Cable Definition	·P.06
Report & Reset	P.08



Report & Reset

- ▶ Press "Enter" to enter the "System Operation" menu.
- Select "Report" or "Reset", enter the page.



- Report the information on the page to your agent to get the Digit Code.
- ▶ Enter the reported Digit Code and press the "*".
- ► The screen displays "Password Correct", complete the "Report" or "Reset" process.

CAUTION

The data of "Total Profit" and " Current Profit" in the "Reset" page is generated Instantly. Don't return to the game state before complete the "Reset" process. That will lead to changes in the data, the reported Digit Code can not be used.

Game Description

☆ [Game play instructions]

《Ocean Christmas》 Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 2/3/4/6/8/10 while online games. 21 different types of fish, 11 kinds of powerful special weapons, a clear definition and a detailed undersea scene. It's the most popular game machine in your game center.

☆ 【 Game Features Description 】

▶ Special item—Floating in the field. Attack them to release special power!!

◆ Christmas Gift→ Catch any fish may drop

One sock can play Christmas Gift one time.

◆ Christmas Star→ Hit it may drop gifts.

Get Christmas star will attack the fishes on the field.

♦ Frosty Snowman→ The fishes in the Snowman's path will be frozen.

♦ Happy Bell → Launching multiple sound wave attacks.

◆ Squid King→ Attack the fishes on the field with the Squid King's

tentacles.

◆ Shining Pearl→ Pearl's magic will attack the fishes in the range.

◆ Rumble Fish → Blasting on the seabed.

◆ Chain Lightning→ Attack fishes in the field continuously.

◆ Fish King→ Catch all same kind of fishes.

◆ Lucky Cat→ The golden dragon may catch Lucky Cat.



Special Fish

◆ Lucky Fish→ When killing the lucky fish, the player will get an

x2~x5 Bonus reward for any kind of fish.




Game Description

☆ [Odds Table]



Cable Definition

☆ [Anti-shock wiring diagram]



Signal wire for clip-on coin acceptor.

Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

Operating Instructions

☆ [Operation Panel Instruction]



★ Basic Operations

▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

CAUTION

- ◆ Auto Attack→ Press the "Shoot Button" 3 seconds to launch.
- ◆ Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.
- ◆ Alliance → Hold up to open unite menu. Select one unite to join.

☆ [Play skills]

▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster. If you are lucky, get the biggest 400 bet fish multiply 10 times is not just dreaming.

System Adjustment

☆ [Parameter Adjust—Direct Adjust]

ltem	Default	Parameters
Minimum Bet	50	1~10,20,30,40,50,100~500,1000~5000,9999
Maximum Bet	1000	1~10,20,30,40,50,100~500,1000~5000,9999
Bet increase rate	10	1~10,20,30,40,50,100~500,1000~5000,9999
Credit Limit	1000000	5000,6000,10000,15000,20000,25000,30000,40000,50000,100000,150000,200000,250000,400000,500000,1000000,2000000,2500000,4000000,5000000,10000000,20000000,20000000,25000000,4000000,40000000,50000000,90000000
System Limit	2000000	30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 250000 , 300000 , 400000 , 500000 , 600000 , 800000 , 1000000 , 2000000 , 2500000 , 2700000 , 3000000 , 4000000 , 5000000 , 6000000 , 8000000 , 10000000 , 20000000 , 25000000 , 30000000 , 40000000 , 50000000 , 60000000 , 80000000 , 90000000
Ticket Ratio	1	1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/8 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 30 , 35 , 40 , 45 , 50 , 80 , 100
Withdraw Mode	Menu (Coin)	Menu(Coin), Menu(Ticket), Key out (Coin), Key out (Ticket), Game (Coin), Game (Ticket), Print Voucher
Shooting Speed	Medium	Fast , Slow , Medium
Bullet Speed	Medium	Fast , Slow , Medium
Auto Trigger Time	No	Fast , No , Slow , Medium
Auto shoot	On	Off,On
LOCK	On	Off, On
Player Steering	Standard	Standard , Inverse
Station Quan- tity	8(3-1)	2(2-0), 3(3-0), 4(2-0), 4(4-0), 6(2-1), 6(3-0), 8(2-2), 8(3-1), 8(4-0), 10(3-2), 10(4-1)
BGM	On	Off, On, SE, BGM
Volume	4	0,1,2,3,4,5,6,7,8

System Adjustment

☆ [Parameter Adjust—Report Adjust]

ltem	Default	Parameters
Coin Ratio	100	0~5,10,20,25,40,50,100,200,250,400, 500,1000~5000,10000
Key In Ratio	1000	0,10,20,25,40,50,100,200,250,400, 500,1000~5000,10000~50000,100000
Game Difficulty	6	0 ~ 20
Location Scale	Medium Location	Small Location、Medium Location、Large Location
Bonus odds rate	Mid	Low , Mid , High ,off
Report Time period	10	0~30
Profit Limit to Report	100000	0,10000,20000,30000,,300000
System Time	-	
Change Password	-	

CAUTION

Total record default password : [0000 0000]