



# User's Manual

# Index

- **Game Description** ..... P.01
- **Operating Instructions** ..... P.03
- **System Adjustment** ..... P.04
- **Cable Definition** ..... P.06
- **Report & Reset** ..... P.07

# Game Description

## ★ [ Game play instructions ]

《MAGIC WINDBELL》 Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 2 / 3 / 4 / 6 / 8 / 10 while online games. 22 different types of fish, 10 kinds of powerful special weapons, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

## ★ [ Game Features Description ]

### ▶ Special item — Floating in the field. Attack them to release special power!!

- ◆ Chain Lightning→ Attacking fishes in the field continuously.
- ◆ Octopus Bomb→ Killing it drop a bomb cause octopus get mad and fooling around. Press attack button cause bomb explode .
- ◆ Devastating Bomb→ Killing inflated red octopus explode the Devastating Bomb. kill all fish in the field. (excluding special fishes).
- ◆ God of Wealth→ Press the attack button to shock the treasure bowl. The God of Wealth will randomly send rewards.
- ◆ Golden Medal→ Summon Wooden Mechanical Kite to attack all fishes in the field.
- ◆ Ocean Award→ Win big rewards.
- ◆ Magic Windbell→ Summon a note bomb or magical attack on a wide range of fish.

### ▶ Special Fish

- ◆ Lucky Fish→ When killing the lucky fish, player will get a x2~x10 Bonus reward for any kind of fish.
- ◆ Armored Dragon→ Armored Dragon have an opportunity to transform into a stronger dragon.  
Destroy stronger dragon can get 1000~1250 bonus rewards.
- ◆ Lucky Card→ Scrape out 3 identical prizes, win the prize. There have 3 chances to win.

# Game Description

## ★ [ Odds Table ]

			
x2	x3	x4	x4
			
x5	x5	x8	x8
			
x10	x10	x12	x15
			
x18	x20	x25	x30
			
x40	x50	x100	x200
			
x400		x800~1000	

# Operating Instructions

## ★ [ Operation Panel Instruction ]



## ★ [ Basic Operations ]

- ▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

### ! CAUTION

- ◆ **Auto Attack** → Press the "Shoot Button" 3 seconds to launch.
- ◆ **Aim Attack** → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

## ★ [ Play skills ]

- ▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster. If you are lucky, get the biggest 400 bet fish multiply 10 times is not just dreaming.

# System Adjustment

## ☆ 【 Parameter Adjust—Direct Adjust 】

Item	Default	Parameters
Minimum Bet	50	1~10,20,30,40,50,100~500,1000
Maximum Bet	1000	1~10,20,30,40,50,100~500,1000
Bet Increase Rate	10	1~10,20,30,40,50,100~500,1000
Credit Limit	1000000	5000,6000,10000,15000,20000,30000,50000,100000,150000,200000,500000,1000000,2000000,5000000,9000000
System Limit	5000000	10000,15000,20000,30000,40000,50000,100000,150000,200000,300000,500000,1000000,2000000,5000000,9000000
Ticket Ratio	1	1/100,1/80,1/50,1/25,1/15,1/10,1/8,1/5,1/4,1/3,1/2,1,2,3,4,5,8,10,15,20,25,50,80,100
Withdraw Mode	Key Out (Coin)	Key Out (Coin), Key Out (Ticket), Ticket out in game, Coin out in game, Auto Out(Coin), Auto Out (Ticket),Immidiata keyout
Shooting Speed	Medium	Slow, Medium, Fast
Bullet Speed	Medium	Slow, Medium, Fast
Auto Trigger Time	No	No、Slow、Medium、Fast
Auto shoot	On	Off, On
LOCK	On	Off, On
Station Quantity	8(3-1)	2(2-0), 3(3-0), 4(2-2), 4(4-0), 6(2-1), 6(3-0), 8(2-2), 8(3-1), 8(4-0), 10(3-2), 10(4-1)
BGM	On	Off, On, SE, BGM
Volume	4	0,1,2,3,4,5,6,7,8

# System Adjustment

## ★ 【 Parameter Adjust—Report Adjust 】

Item	Default	Parameters
Coin Ratio	100	1~10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000
Key In Ratio	1000	100 , 200 , 250, 500 , 1000 , 2000 , 2500, 5000, 10000 , 20000 , 25000, 50000,100000
Game Difficulty	6	0~20
Location Scale	Medium Location	Small Location , Medium Location , Large Location
Bonus Odds Rate	Mid	Off , Low , Mid , High
Report Time period	10	1 ~ 30
Profit Limit to Report	100000	10000 ~ 300000
System Time	-	
Change Password	-	



Total record default password : 『 0000 0000 』


# Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground



# Report & Reset

- ▶ Press “Enter” to enter the “System Operation” menu.
- ▶ Select “Report” or “Reset” , enter the page.



- ▶ Report the information on the page to your agent to get the Digit Code.
- ▶ Enter the reported Digit Code and press the “\*” .
- ▶ The screen displays "Password Correct", complete the “Report” or “Reset” process .

## CAUTION

The data of “Total Profit” and “Current Profit” in the “Reset” page is generated Instantly. **Don’ t return to the game state before complete the “Reset” process** . That will lead to changes in the data, the reported Digit Code can not be used.



# Note



# Note

