



# User's Manual

# Index

- **Game Description** ..... P.01
- **Operating Instructions** ..... P.03
- **System adjustment** ..... P.04
- **Cable definition** ..... P.06

# Game Description

## ★【Game play instructions】

《Dragon Ball》 Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 19 different types of fish, 9 kinds of powerful special Items, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

## ★【Game Features Description】

### ▶ Special item— Floating in the field. Attack them to release special power!!

- ◆ Dragon Ball→ Randomly upgrade normal bullet to powerful Dragon Ball for free.
- ◆ Blasting Firecracker→ Cause Blasting Firecracker explode while defeated. Attacking all fishes near exploding area.
- ◆ Ancient Cannon→ Cause Ancient Cannon explode while defeated. Killing all normal fish in the field at once.

### ▶ Special Fish

- ◆ Fish King → Kill all same kind fishes in the field.
- ◆ Treasure Dragonboat → Attack Treasure Dragonboat has a chance to drop random jewelry. Success break it will win high score award.
- ◆ Pearl Roulette → Collect 5 jewels drop form the Treasure Dragonboat will launch Pearl Roulette. Win the additional bonus scores.
- ◆ Flame Dragon → Get x500~800 randomly.
- ◆ Golden Lobster → Get x200~500 randomly.
- ◆ Crimson Lobster → Get x100~200 randomly.

# Game Description

## ★【Odds Table】

|   |   |   |
|---|---|---|
|    |    |    |
| x2  | x2  | x3  |
|    |    |    |
| x4  | x5  | x6  |
|    |    |    |
| x7  | x8  | x9  |
|    |    |    |
| x10   | x12   | x15   |
|   |   |   |
| x18   | x20   | x25   |
|  |  |  |
| x30   | x40   | x60   |
|  |   |   |
| x80   |   |   |

# Operating Instructions

## ★【Operation Panel Instruction】



## ★【Basic Operations】

- ▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

### ! CAUTION

- ◆ **Auto Attack** → Press the "Shoot Button" 3 seconds to launch.
- ◆ **Aim Attack** → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

## ★【Play skills】

- ▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster.

# System Adjustment

## ★ [Parameter Adjust-Direct Adjust]

| Item              | Default       | Parameters   |
|-------------------|---------------|--|
| Minimum Bet       | 50            | 1 , 2 , 5 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 250   |
| Maximum Bet       | 1000          | 10 , 20 , 30 , 40 , 50 , 100 , 200 , 500 , 1000  |
| Bet Increase Rate | 10            | 1 , 2 , 5 , 10 , 20 , 50 , 100 , 200 , 500 , 1000  |
| Credit Limit      | 1000000       | 5000 , 6000 , 10000 , 15000 , 20000 , 30000 , 50000 , 100000 , 150000 , 200000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000    |
| System Limit      | 2000000       | 10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000 |
| Ticket Ratio      | 1             | 1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/08 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100                                  |
| Withdraw Mode     | KeyOut (Coin) | KeyOut(Coin) 、 KeyOut(Ticket) 、 AutoOut(Coin) 、 AutoOut(Ticket)  |
| Shooting Speed    | Medium        | Slow 、 Medium 、 Fast   |
| Bullet Speed      | Medium        | Slow 、 Medium 、 Fast   |
| AutoTrigger-Time  | No            | No 、 Slow 、 Medium 、 Fast  |
| Auto shoot        | On            | Off 、 On   |
| Station Quantity  | 8(3-1)        | 2(2-0) , 3(3-0) , 4(2-2) , 4(4-0) , 6(2-1) , 8(2-2) , 8(3-1) , 8(4-0) , 8(8-0) , 10(3-2)   |
| BGM               | On            | Off 、 On 、 SE 、 BGM  |
| Volume            | 4             | 0 , 1 , 2 , 3 , 4 , 5 , 6 , 7 , 8  |

# System Adjustment

## ★【Parameter Adjust-Report Adjust】

| Item                   | Default         | Parameters   |
|------------------------|-----------------|--|
| Coin Ratio             | 100             | 1 , 2 , 5 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000                               |
| Key In Ratio           | 10000           | 100 , 200 , 250 , 500 , 1000 , 2000 , 2500 , 5000 , 10000 , 20000 , 25000 , 50000 , 100000 |
| Game Difficulty        | 5               | 0 , 1 , 2 , 3 , 4 , 5  |
| Location Scale         | Medium Location | Small Location、 Medium Location、 Large Location  |
| Report Time period     | 10              | 1 ~ 30   |
| Profit Limit to Report | 100000          | 10000 ~ 300000   |
| System Time            | --              | YYYY/MM/DD HH:MM:SS  |
| Change Password        | 00000000        |  |



Total record default password : 『 0000 0000 』

# Cable Definition

|            |    |    |                |
|------------|----|----|----------------|
| Up         | 1  | 2  | Down           |
| Left       | 3  | 4  | Right          |
| Raise bet  | 5  | 6  | Shoot          |
| Coin in    | 7  | 8  | Key in         |
| Key out    | 9  | 10 | Pay out        |
| Ticket SW  | 11 | 12 | Hopper SW      |
| Ticket SSR | 13 | 14 | Hopper SSR     |
| Shoot lamp | 15 | 16 | Raise bet lamp |
| +12V       | 17 | 18 | +12V           |
| +12V       | 19 | 20 | +12V           |
| +5V        | 21 | 22 | Ground         |
| Ground     | 23 | 24 | Ground         |
| Ground     | 25 | 26 | Ground         |





# NOTE



# NOTE



# NOTE

