



VGAME\_Bella (Taiwan)

Add Whatsann



20230923 F100BEN

User's Manual



Game Description	···P.01
Operating Instructions ······	··P.03
System Adjustment	P.0∠
Cable Definition	··P.06
Report & Reset	···P.07

# Note

# Report & Reset

- ▶ Press "Enter" to enter the "System Operation" menu.
- ▶ Select "Report" or "Reset", enter the page.



- Report the information on the page to your agent to get the Digit Code.
- ► Enter the reported Digit Code and press the "\*".
- ► The screen displays "Password Correct", complete the "Report" or "Reset" process.

#### CAUTION

The data of "Total Profit" and " Current Profit" in the "Reset" page is generated Instantly. Don't return to the game state before complete the "Reset" process. That will lead to changes in the data, the reported Digit Code can not be used.

# Game Description

### ☆ (Came play instructions)

«Mermaid World» Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 2/3/4/6/8/10 while online games. 12 different types of fish, 2 kinds of powerful special weapons, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

#### ☆ [Game Features Description]

- ► Special weapons—Killing any fish will drop special weapon randomly.
  - ◆ Flying Fish → Randomly upgrade normal bullet to powerful flying fish for free.
- ▶ Special item—Floating in the field. Attack them to release special power!!
  - ◆ Puffer Bomb → After attacking, it bounces everywhere and explodes.
  - ◆ Drill Bomb → Kill the crab carrying Drill Bomb will get it. Decide the direction then attack all the fishes on the line. (Base x30.bounce after hit walls)
- ► LUCKY MERMAID—Attack the mermaid has a chance to enter the mini game.
  - ◆ Lucky Slot→ Awarded according to the pattern on the slot.
  - ♦ Morra Challenge → Win more times, will get more rewards.


# Game Description

### ☆ (Odds Table)



## Cable Definition

### ★ [Anti-shock wiring diagram]



Signal wire for clip-on coin acceptor.

# Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

# Operating Instructions

### ☆ (Operation Panel Instruction )



#### ★ [Basic Operations ]

▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

### CAUTION

- ◆ Auto Attack→Press the "Shoot Button" 3 seconds to launch.
- ◆ Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

#### A [Play skills]

▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster.

# System Adjustment

### ☆ (Parameter Adjust—Direct Adjust)

ltem	Default	Parameters
Minimum Bet	50	1~9 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 300 , 400 , 500 , 1000
Maximum Bet	1000	1 ~ 9, 10, 20, 30, 40, 50, 100, 200, 300, 400, 500, 1000
Bet Increase rate	10	1~9, 10,20, 30, 40, 50,100,200, 300, 400, 500,1000
Credit Limit	1000000	5000,6000,10000,15000,20000,30000,50000, 100000,150000,200000,500000,1000000, 2000000,5000000,10000000,20000000, 50000000,90000000
System Limit	2000000	10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 20000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000
Ticket Ratio	1	1/100, 1/80, 1/50, 1/25, 1/20, 1/15, 1/10, 1/8, 1/5, 1/4, 1/3, 1/2, 1, 2, 3, 4, 5, 8, 10, 15, 20, 25, 30, 35, 40, 45, 50, 80, 100
Withdraw Mode	Menu (Coin)	Key Out (Coin) , Key Out (Ticket) , Menu(Coin) , Menu (Ticket) , Game(Coin) , Game(Ticket) , Print voucher , Communication Mode
Shooting Speed	Medium	Slow , Medium , Fast
Bullet Speed	Medium	Slow , Medium , Fast
Auto Trigger Time	No	No \ Slow \ Medium \ Fast
Auto shoot	On	Off, On
Player Steering	Standard	Inverse , Standard
Station Quantity	8(3-1)	2 (2-0), 3 (3-0), 4 (2-0), 4 (4-0), 6 (2-1), 6 (3-0), 8 (2-2), 8 (3-1), 8 (4-0), 10 (3-2), 10 (4-1)
BGM	On	Off, On, SE, BGM
Volume	4	0,1,2,3,4,5,6,7,8

# System Adjustment

### ☆ (Parameter Adjust—Report Adjust)

ltem	Default	Parameters
Coin Ratio	100	1~9 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000
Key In Ratio	1000	100 , 200 , 250, 500 , 1000 , 2000 , 2500, 5000,10000,20000,25000, 50000,100000
Game Difficulty	6	0,1~20
Location Scale	Medium Location	Small Location , Medium Location , Large Location
Special Weapon rate	Mid	Low , Mid , High
Bonus Odds Rate	Mid	Low , Mid , High
Report Time period	10	0,1~30
Profit Limit to Report	100000	0,10000~300000
System Time	-	
Change Password	-	

### CAUTION

Total record default password : 「0000 0000 』