FISHERMAN CLUB USA 2

User's Manual

Index

Game Description

《Fisherman Club 2 USA》 Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, the use of full-color high-definition scene dynamic production, support 4 / 6 / 8 / 10 while online games. 19 different types of fish, 11 kinds of powerful special weapons, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

☆【Game Features Description】

▶ Special Weapons—Suddenly appear Energy Laser, Power Grid and Invincible Bomb for FREE!! In addition to its amazing visual effects, it also gives you High-Score rewards. (Special weapons will shoot automatically if player didn't launch in 5 minutes.

◆ Energy Laser➡   Slit fishes in a straight forward direction.
◆ Power Grid ➡   Laying in the field continuously for 5 seconds .
◆ Invincible Bomb➡   Damage all fishes in the field at a time .

▶ Special Reward Items—Floating in the field. Attack them to release special power!!

◆ Drill Bomb➡   Kill the crab carrying Drill Bomb will get it. Decide the direction then attack all the fishes on the line. (Base x120,bounce after hit walls)

◆ Chain Lightning➡   Kill the Golden Eel will release electricity, attacking fishes in the field continuously.

◆ Thom Bomb➡   Shoot the Thom Bomb cause undersea storm!! The storm will attack all fishes in the field.

▶ Special Fishes

◆ Fish King➡   Surrounded by dolphin ring. Killing the Fish King also kill all same kind of fishes in the field and get scores.

◆ Lucky Fish➡   When killing the lucky fish, player will get a x2~x10 Bonus reward for any kind of fish. Maximum reward is 1000 time Bets!!

Game Description

x2	x3	x4	x4
x5	x5	x8	x8
x10	x10	x12	x15
x18	X20	x25	x30
x40	x50	x100	
x 100-400		x200-800	
x300-1200			

02

Operating Instructions

《Direction Controller 》   《Shoot》   《Raise Bet 》

☆【Basic Operations 】

▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

☆【Special Operation 】

▶ Auto Attack, Aim Attack makes the game operation more convenient and easy!! You can hit any fish as you wish!!

◆ Auto Attack ➡Press the "Shoot Button" 3 seconds to launch.
◆ Aim Attack ➡Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

☆【Play skills 】

▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster. If you are lucky, get the biggest 100 bet fish multiply 10 times is not just dreaming.

System Adjustment

Item	Default	Values
Minimum Bet	10	1、2、5、10、20、30、40、50、100、200、250
Maximum Bet	1000	10、20、30、40、50、100、200、500、1000
Bet Increase Rate	10	1、2、5、10、20、50、100、200、500、1000
Credit Limit	1000000	5000、6000、10000、15000、20000、30000、50000、100000、150000、200000、500000、1000000、2000000、5000000、10000000、20000000、50000000、90000000
System Limit	5000000	10000、15000、20000、30000、40000、50000、100000、150000、200000、300000、500000、1000000、2000000、5000000、10000000、20000000、50000000、90000000
Ticket Ratio	1	1/100、1/80、1/50、1/25、1/15、1/10、1/8、1/5、1/4、1/3、1/2、1、2、3、4、5、8、10、15、20、25、50、80、100
Withdraw Mode	KeyOut (Coin)	KeyOut(Coin)、KeyOut(Ticket)、AutoOut(Coin)、AutoOut(Ticket)、Immidiate key-out、Coin out in game、Ticket out in game
Shooting Speed	Medium	Slow、Medium、Fast
Bullet Speed	Medium	Slow、Medium、Fast
Auto Trigger Time	Medium	No、Slow、Medium、Fast
Auto shoot	On	On、Off
LOCK	On	On、Off
Station Quantity	8(3-1)	4(2-2) , 4(4-0) , 6(2-1) , 8(3-1) , 10(3-2)
BGM	On	Off、On、SE、BGM
Volume	4	0、1、2、3、4、5、6、7、8

System Adjustment

Item	Default	Parameters
Coin Ratio	100	1 , 2 , 5 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000
Game Difficulty	6	0~20
Location Scale	Medium Location	Small Location、Medium Location、Big Location
Special weapon rate	Mid	Low、Mid、High
Bonus odds rate	Mid	Low、Mid、High
Report Time period	10	1 ~ 30
Profit Limit to Report	100000	10000 ~ 300000
System Time	-	
Change Password	-	

CAUTION

Total record default password ： 『 0000 0000 』

Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

Note

Note