



Index

Game Description	Р	.1
Operating Instruct	ionsP	.3
System adjustment	Р	'.4
Cable definition	P	.6

Game Description

◆ Game play instructions

《Fisherman Club》 Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, the use of full-color high-definition scene dynamic production, support 4 / 6 / 8 / 10 while online games. 19 different types of fish, 7 kinds of powerful special weapons, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

◆ Game Features Description

Suddenly appear special weapons—Energy Laser, Power Grid and Invincible Bomb for FREE!! In addition to its amazing visual effects, it also gives you High-Score rewards. (Special weapons will shoot automatically if player didn't launch in 5 minutes.

Energy Laser—Slit fishes in a straightforward direction Power Grid—Last in the fields in a sustained 5 seconds Invincible Bomb—Damage all fishes in the field at a time

Special Reward Items

Breaker Throneball—Kill blowfish while lighted up will dorp breaker throneball.Rolling in the field attacking fishes. (bounce after hit walls)

Fish King—Fishes surrounded by dolphin ring become Fish King. Killing the Fish King causes all same kind of fishes in the field die and gets the scores.


Mermaid Explosion—Combination of Angel Mermaid and Mega Explosion!!

Kill all normal fishes in the field.

• Lucky Fish—When killing the lucky fish, player will get a x2~x10 Bonus reward for any kind of fish. Maximum reward is 1000 time Bets!!

• Convenient Operation: Auto Attack, Aim Attack makes the game operation more convenient and easy!! You can hit any fish as you wish!!

Game Description



Operating Instructions

Operation Panel Instruction Direction Controller Shoot Raise Bet

Basic Operations

It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!



Play skills

Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster. If you are lucky, get the biggest 100 bet fish multiply 10 times is not just dreaming.



Special Operation

Auto Attack: Press the "Shoot Button" 3 seconds to launch. Aim Attack: Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

System adjustment

Host adjustment—Direct

Direct Adjust							
Item Default		Values					
	values	1 2 5 10 20 20 40 50 100 200					
Minimum Bet	10	1, 2, 5, 10, 20, 30, 40, 50, 100, 200, 250, 300, 400, 500, 600, 700, 800, 900, 1000, 1500, 2000, 2500, 3000, 4000, 5000					
Maximum Bet	1000	1500, 2000, 2500, 3000, 4000, 5000 10, 20, 30, 40, 50, 100, 200, 500, 1000, 2000, 3000, 5000, 9999					
Bet Increase	10	1 , 2 , 5 , 10 , 20 , 50 , 100 , 200 , 500 , 1000					
Credit Limit	1000000	5000 , 6000 , 10000 , 15000 , 20000 , 30000 , 50000 , 100000 , 150000 , 200000 , 500000 , , 1000000 , 2000000 , 5000000 , 1000000 , , , , 20000000 , 5000000 , 90000000 , 1000000 , <t< td=""></t<>					
System Limit	5000000						
Ticket Ratio	1						
Withdraw Mode	KeyOut (Coin)	KeyOut(Coin) 、KeyOut(Ticket) 、AutoOut(Coin) 、 AutoOut(Ticket) 、Immidiate keyout 、Ticket out in game 、Coin out in game					
Shooting Speed	Medium	Slow、Medium、Fast					
Bullet Speed Medium		Slow、Medium、Fast					
AutoTrigger- Time Medium		Off 、Slow、Medium、Fast					
Auto Shooting	On	Off • On					
Lock	On	Off、On					
Station Quan- tity 8		3 , 4 , 6 , 8 , 10					
BGM	On	Off、On、SE、BGM					
Volume 4		0,1,2,3,4,5,6,7,8					

System adjustment

Report Adjust

Report Adjust							
Item	Default	Parameters					
Coin Ratio	100	1 , 2 , 5 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000					
Game Difficulty	2 0,1,2,3,4,5						
Location Scale	Medium Location	Small Location · Medium Location · Big Location					
Special weapon rate	Mid	Low、Mid、High					
Bonus odds rate	Mid	Low、Mid、High					
Report Time period	10	1 ~ 30					
Profit Limit to Re- port	100000	10000 ~ 300000					
System Time	-						
Change Password	-						

Default Password is ©0000 0000 』

Cable definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground