



User's Manual

Index

- [Game Description](#)P.01
- [Operating Instructions](#)P.03
- [System adjustment](#)P.04
- [Cable definition](#)P.06

Note

Note

Game Description

★【Game play instructions】

《Insect Elves》 based on the natural insect theme of the plane LCD monitor lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of insect, 12 kinds of powerful special weapons, a clear definition and detailed nature scene. It's the most popular game machine in your Game center.

★【Game Features Description】

▶ Special item—Floating in the field. Attack them to release special power!!

- ◆ Spider Bomb → Killing it will drop a bomb cause spider get mad and fooling around. Press attack button cause bomb explode attacking nearby insects.
- ◆ Hyper Spider Bomb → Killing the enraged spider when it get larger cause the hyper bomb explode, attacking all insects in the field at once.
- ◆ Sticky Hive → Stick all insects nearby, kill trapped insects will double scores.
- ◆ Blasting Centipede → After destroying it, parts of the body will spread, turn into bomb and explode.
- ◆ Lightening Scorpion → Kill the Lighting Scorpion may release electricity from the tail, chain electric shock nearby insects .
- ◆ Mantis Saber → Killing it to shoot 2 Mantis Saber towards the ends of the line ,attack all insects in the line.
- ◆ Machine gun ant → Defeating Machine gun ant causes it down to ground and launch machine gun fire, attacking surrounding insects .
- ◆ Timer Bomb → Attack all insects in the field.
- ◆ Drill Snail → Kill the Drill Snail can get 120 times score, and get the drill bomb.
- ◆ Volcanic Beast → Hit the Volcanic Beast may fall one rock with attack effect. Defeat the Volcanic Beast will lead full-screen rock attack.
- ◆ Yellow Chick → Become bomb to attack insects.
- ◆ Flower Elf → Dance to attack insects.

▶ Special Insect

- ◆ Lucky Insect → Killing any huge insect has a chance to become Lucky Insect to get 2 to 10 times scores.
- ◆ Cherry blossom Dragon → Random odds from 150~600x.

Game Description

Note

★(Odds Table)


| | | | |
|---|--|---|--|
|  |  |  |  |
| x2 | x3 | x4 | x5 |
|  |  |  |  |
| x8 | x10 | x12 | x15 |
|  |  |  |  |
| x18 | x20 | x25 | x30 |
|  |  |  |  |
| x40 | x60 | x80 | x100 |
|  | |  | |
| x200 | | x400 | |
|  | |  | |
| x500 | | x150~600 | |

Cable Definition

| | | | |
|------------|----|----|----------------|
| Up | 1 | 2 | Down |
| Left | 3 | 4 | Right |
| Raise bet | 5 | 6 | Shoot |
| Coin in | 7 | 8 | Key in |
| Pay out | 9 | 10 | Key out |
| Ticket SW | 11 | 12 | Hopper SW |
| Ticket SSR | 13 | 14 | Hopper SSR |
| Shoot lamp | 15 | 16 | Raise bet lamp |
| +12V | 17 | 18 | +12V |
| +12V | 19 | 20 | +12V |
| +5V | 21 | 22 | Ground |
| Ground | 23 | 24 | Ground |
| Ground | 25 | 26 | Ground |

Operating Instructions

★【Operation Panel Instruction】



★【Basic Operations】

- ▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

! CAUTION

- ◆ **Auto Attack** → Press the "Shoot Button" 3 seconds to launch.
- ◆ **Aim Attack** → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

★【Play skills】

- ▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at insects cluster. If you are lucky, get the biggest 100 bet insect multiply 10 times is not just dreaming.

System Adjustment

★【Parameter Adjust—Direct Adjust】

| Item | Default | Values |
|-------------------|---------------|--|
| Minimum Bet | 50 | 1~10、20、30、40、50、100、200、300、400、500、1000、2000 |
| Maximum Bet | 1000 | 1~10、20、30、40、50、100、200、300、400、500、1000、2000 |
| Bet Increase Rate | 10 | 1、2、5、10、20、50、100、200、500、1000 |
| Credit Limit | 1000000 | 5000、6000、10000、15000、20000、30000、50000、100000、150000、200000、500000、1000000、2000000、5000000、10000000、20000000、50000000、90000000 |
| System Limit | 5000000 | 10000、15000、20000、30000、40000、50000、100000、150000、200000、300000、500000、1000000、2000000、5000000、10000000、20000000、50000000、90000000 |
| Ticket Ratio | 1 | 1/100、1/80、1/50、1/25、1/15、1/10、1/8、1/5、1/4、1/3、1/2、1、2、3、4、5、8、10、15、20、25、50、80、100 |
| Withdraw Mode | KeyOut (Coin) | KeyOut(Coin)、KeyOut(Ticket)、Coin out in game、Ticket out in game |
| Shooting Speed | Medium | Slow、Medium、Fast |
| Bullet Speed | Medium | Slow、Medium、Fast |
| Auto Trigger Time | No | No、Slow、Medium、Fast |
| Auto Shoot | On | On、Off |
| Lock | On | On、Off |
| Station Quantity | 8(3-1) | 2(2-0)、3(3-0)、4(2-2)、4(4-0)、6(2-1)、6(3-0)、8(2-2)、8(3-1)、8(4-0)、10(3-2)、10(4-1) |
| BGM | On | Off、On、SE、BGM |
| Volume | 4 | 0、1、2、3、4、5、6、7、8 |

System Adjustment

★【Parameter Adjust—Report Adjust】

| Item | Default | Values |
|------------------------|-----------------|--|
| Coin Ratio | 100 | 1、2、5、10、20、25、50、100、200、250、500、1000 |
| Key In Ratio | 1000 | 100、200、250、500、1000、2000、2500、5000、10000、20000、25000、50000、100000 |
| Game Difficulty | 5 | 0~15 |
| Location Scale | Medium Location | Small Location、Medium Location、Big Location |
| Bonus odds rate | Mid | Low、Mid、High |
| Report Time period | 10 | 0~30 |
| Profit Limit to Report | 100000 | 10000~300000 |
| System Time | - | |
| Change Password | - | |



Total record default password : 「 0000 0000 」