



User's Manual

Index

- [Game Description](#)P.01
- [Operating Instructions](#)P.03
- [System adjustment](#)P.04
- [Cable definition](#)P.06

Note

Note

Game Description

★【Game play instructions】

《Lucky Insect》 based on the natural insect theme of the plane LCD monitor lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 18 different types of insect, 13 kinds of powerful special weapons, a clear definition and detailed nature scene. It's the most popular game machine in your Game center.

★【Game Features Description】

▶ Special item—Floating in the field. Attack them to release special power!!

- ◆ Spider Bomb → Killing it will drop a bomb cause spider get mad and fooling around. Press attack button cause bomb explode attacking nearby worms.
- ◆ Hyper Spider Bomb → Killing the enraged spider when it get larger cause the hyper bomb explode, attacking all worms in the field at once.
- ◆ Sticky Hive → Stick all insects nearby, kill trapped worms will double scores.
- ◆ Blasting Centipede → After destroying it, parts of the body will spread, turn into bomb and explode.
- ◆ Lightening Scorpion → Kill the Lighting Scorpion may release electricity from the tail.
- ◆ Mantis Saber → Killing it to shoot 2 Mantis Saber towards the ends of the line.
- ◆ Machine gun ant → Launch machine gun fire, attacking surrounding insects.
- ◆ Timer Bomb → Attack all bugs in the field.
- ◆ Drill Snail → Kill the Drill Snail can get 120 times score, and get the drill bomb.
- ◆ Demon Mermaid → Shoot pinpricks to attack nearby worms.
- ◆ Mermaid Explosion → Kill all normal worms in the field.
- ◆ Lucky Lotus → Petals fall and attack nearby worms.
- ◆ Lucky Worm → Killing any Royal Beetle has a chance to become Lucky Worm to get 2 to 10 times scores.

Game Description

Note

★(Odds Table)


			
x2	x3	x4	x5
			
x8	x10	x12	x15
			
x18	x20	x25	x30
			
x40	x60	x80	x100

Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Pay out	9	10	Key out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground

Operating Instructions

★【Operation Panel Instruction】



★【Basic Operations】

- ▶ It's easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

! CAUTION

- ◆ **Auto Attack** → Press the "Shoot Button" 3 seconds to launch.
- ◆ **Aim Attack** → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

★【Play skills】

- ▶ Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at insects cluster. If you are lucky, get the biggest 100 bet insect multiply 10 times is not just dreaming.

System Adjustment

★【Parameter Adjust—Direct Adjust】

Item	Default	Values
Minimum Bet	10	1、2、5、10、20、30、40、50、100、200、250
Maximum Bet	1000	8、10、20、30、40、50、100、200、500、1000、2000
Bet Increase Rate	10	1、2、5、10、20、50、100、200、500、1000
Credit Limit	1000000	5000、6000、10000、15000、20000、30000、50000、100000、150000、200000、500000、1000000、2000000、5000000、10000000、20000000、50000000、90000000
System Limit	5000000	10000、15000、20000、30000、40000、50000、100000、150000、200000、300000、500000、1000000、2000000、5000000、10000000、20000000、50000000、90000000
Ticket Ratio	1	1/100、1/80、1/50、1/25、1/15、1/10、1/8、1/5、1/4、1/3、1/2、1、2、3、4、5、8、10、15、20、25、50、80、100
Withdraw Mode	Key Out (Coin)	Key Out (Coin)、Key Out (Ticket)、Coin out in game、Ticket out in game
Shooting Speed	Medium	Slow、Medium、Fast
Bullet Speed	Medium	Slow、Medium、Fast
Auto Trigger Time	No	No、Slow、Medium、Fast
Auto Shoot	On	On、Off
Lock	On	On、Off
Station Quantity	8(3-1)	2(2-0)、3(3-0)、4(2-2)、4(4-0)、6(2-1)、6(3-0)、8(2-2)、8(3-1)、8(4-0)、10(3-2)、10(4-1)
BGM	On	Off、On、SE、BGM
Volume	4	0、1、2、3、4、5、6、7、8

System Adjustment

★【Parameter Adjust—Report Adjust】

Item	Default	Values
Coin Ratio	100	1、2、5、10、20、25、50、100、200、250、500、1000
Key In Ratio	1000	100、200、250、500、1000、2000、2500、5000、10000、20000、25000、50000、100000
Game Difficulty	5	0、1、2、3、4、5、6、7、8、9、10、11、12、13、14、15
Location Scale	Medium Location	Small Location、Medium Location、Large Location
Bonus odds rate	Mid	Low、Mid、High
Report Time period	10	0~30
Profit Limit to Report	100000	0、10000~300000
System Time	-	
Change Password	-	

! CAUTION

Total record default password : 『 0000 0000 』