



# ROYAL CLUB



## User's Manual

# Index

- [Game Description](#) .....P.01
- [Game Description Instruction](#) .....P.01
- [Wiring Diagram](#) .....P.02
- [System Operation](#) .....P.03
- [Record System Operating Instructions](#) .....P.04

# Game Description

## ★ 【Game Features】

- ▶ Pure Full house “AAKK” wins the surprise bonus.
- ▶ Pure 4 of a Kind wins **x2~x16** bonus treasure chest.
- ▶ 4 of a Kind(2~10) come continuously, fatal attraction make you hard to leave.
- ▶ Enjoy the top audiovisual in Royal Club.



## ★ 【Game Control Instruction】



Hold 1  
(Half DP)



Hold 2



Hold 3



Hold 4



Hold 5  
(Double DP)



Double Up



Big



Small



Bet



Start  
(Take Score)

# Wiring Diagram

★ 【Wiring Diagram : (36+10)】

|                    |     |     |                        |
|--------------------|-----|-----|------------------------|
|                    | A01 | B01 |                        |
|                    | A02 | B02 |                        |
| Speaker output     | A03 | B03 | Speaker GND            |
| Hold 1 / Half DP   | A04 | B04 |                        |
| Hold 2             | A05 | B05 |                        |
| Hold 3             | A06 | B06 |                        |
| Hold 4             | A07 | B07 |                        |
|                    | A08 | B08 |                        |
| Start / Take Score | A09 | B09 |                        |
| Small              | A10 | B10 |                        |
| Bet                | A11 | B11 |                        |
| Hold 5 / Double DP | A12 | B12 |                        |
| Double Up          | A13 | B13 |                        |
|                    | A14 | B14 |                        |
|                    | A15 | B15 |                        |
| Big                | A16 | B16 |                        |
|                    | A17 | B17 |                        |
| Coin In            | A18 | B18 | Key In                 |
|                    | A19 | B19 |                        |
| Record             | A20 | B20 | Test                   |
| Pay Out            | A21 | B21 | Key Out                |
|                    | A22 | B22 | HP SW                  |
| Coin In list       | A23 | B23 | Lamp of Win Score      |
| Key In list        | A24 | B24 | Lamp of Win Score(Big) |
| Lamp of Error      | A25 | B25 |                        |
|                    | A26 | B26 |                        |
| Coin Out list      | A27 | B27 | Lamp 1                 |
| Key Out list       | A28 | B28 | Lamp 0                 |
| Lamp of Start      | A29 | B29 | Lamp of Hold 1         |
| Lamp of Small      | A30 | B30 | Lamp of Hold 2         |
| Lamp of Bet        | A31 | B31 | Lamp of Hold 3         |
| Lamp of Hold 5     | A32 | B32 | Lamp of Hold 4         |
| Lamp of Double Up  | A33 | B33 | Lamp of Coin Out       |
| Lamp of Big        | A34 | B34 |                        |
|                    | A35 | B35 |                        |
| GND                | A36 | B36 | GND                    |

|        |     |     |     |
|--------|-----|-----|-----|
| GND    | A01 | B01 | GND |
| GND    | A02 | B02 | GND |
| 5V     | A03 | B03 | 5V  |
| 5V     | A04 | B04 | 5V  |
| 12V    | A05 | B05 | 12V |
|        | A06 | B06 |     |
| HP SSR | A07 | B07 |     |
|        | A08 | B08 |     |
| GND    | A09 | B09 | GND |
| GND    | A10 | B10 | GND |

# System Operation

## ★ 【Parameter Adjust-Direct Adjust】

| Options             | Default          | Value  |
|---------------------|------------------|--|
| Coin Ratio          | 10               | 1、 2、 4、 5、 10、 20、 40、 50、 100  |
| Key In Ratio        | 1000             | 10、 40、 50、 100、 200、 400、 500、 1000、 2000、 4000、 5000                   |
| Key Out Ratio       | 1000             | 10、 40、 50、 100、 200、 400、 500、 1000、 2000、 4000、 5000                   |
| Credit Limit        | 200000           | 1、 2、 3、 5、 6、 12、 20、 30、 60 ( Ten thousand )                           |
| System Limit        | 100000           | 1、 2、 3、 5、 6、 8、 10、 12、 20、 30、 50、 60、 100、 150、 200 ( Ten thousand ) |
| Minimum Bet         | 10               | 1、 2、 4、 5、 10、 20、 30、 40、 50、 100、 200、 400、 500、 1000                 |
| Maximum Bet         | 1000             | 100、 200、 500、 1000  |
| Bet increase rate   | 1                | 1、 2、 5、 10、 20、 50、 100、 200、 500                                       |
| Double up limit     | 200000           | No、 2、 3、 5、 6、 12、 20、 30、 60 ( Ten thousand )                          |
| D/up limit bonus    | 50000            | 2000、 5000、 20000、 50000   |
| Qualify Bonus       | 75000            | 5000、 7000、 50000、 75000   |
| Qualify Bonus Score | 4000             | 100、 200、 300、 400、 500、 1000、 2000、 3000、 4000、 5000                    |
| Insurance Bonus     | 7000             | 5000、 7000、 50000、 75000   |
| Hold Rule           | Auto hold option | No、 Auto hold option、 Winning hold                                       |
| Monitor Setting     | AKQJ10           | AKQJ10、 Picture  |
| DEMO BGM            | On               | On、 Off  |
| BGM                 | On               | On、 SE、 BGM、 Off   |
| Volume              | 4                | 0、 1、 2、 3、 4、 5、 6、 7   |

### ! CAUTION

Enter the Direct Adjust page, password is necessary .

Direct Adjust page and Total Record page use the same password.

Change password in Direct Adjust page.

✖ If the Double up limit setting is NO , the double up game will be closed and invalid .

✖ Default password is “0000000” .

# Record System Operating Instructions

## ★ [System Operation]

### ! CAUTION

You can operation with the USB keypad.  
In the situation of betting or selecting the hold cards ,press “Enter” key on the keyboard to enter game Record menu.  
Press “2/8” to move the Cursor Up / Down.  
Press “Enter” to enter the selected option.

▶ **Recent records** (Record last 10 awards content , use “2/8” select prev / next data . Use “Enter” to exit )

▶ **Record**

Current Record ( Press “\*” to reset Current Record )

Total Record ( password is necessary )

▶ **Direct Adjust** ( password is necessary )

After setting up ,select the option “Save & Exit” to save all changes.

▶ **Report**

▶ **Reset**

Both of “Report” and “Reset” , You must return all the data on the screen to the agent, to get a 30-digit Report code .

Then enter the Report code correctly, press the "\*" key for confirmation. Cancellation and exit presses "Enter" .

Wait for the screen appears the word "password correct", " Report code" action is complete.

▶ **Test**

▶ **Exit**

# Record System Operating Instructions

Press the “RECORD” button enter the backend menu.

The following is the mapping of the buttons:

|        |       |  |
|--------|-------|--|
| START  | NUM 0 | Under the condition of can not enter any numbers ,that can act as "Enter" function . |
| HOLD1  | NUM 1 |  |
| HOLD2  | NUM 2 | 『Down』   |
| HOLD3  | NUM 3 |  |
| HOLD4  | NUM 4 | 『Left』 、 『-』   |
| HOLD5  | NUM 5 |  |
| BET    | NUM 6 | 『Right』 、 『+』  |
| WUP    | NUM 7 |  |
| SMALL  | NUM 8 | 『Up』   |
| BIG    | NUM 9 |  |
| PAYOUT |       | 『*』  |
| RECORD |       | 『Enter』  |



**ROYAL CLUB**