



# Gong Xi Fa Cai

A stack of gold coins and gold ingots. The top two are gold ingots, and the bottom two are gold coins with a circular pattern on their faces. The text 'Gong Xi Fa Cai' is superimposed over this stack.

User's Manual

# Index

- **Instructions** ..... P.01
- **Gameplay & Prize** ..... P.02
- **System Operation** ..... P.06
- **Connection Diagram** ..... P.07

# Instructions

《Gong Xi Fa Cai》 is a video slot game with 5 x 3 reels. After coin in, player can choose bet on 243 payline.



Player also can use "Bet" or "Max Bet" button to decide the bet. Press "Start" button to launch the reels. While the reels spin, player can stop the reels by using "Stop 1" ~ "Stop 5" or "Stop All" button. When all the reels stop, if there are "three or more" consecutive same symbols on any selected paylines "start from left to right", player will win the corresponding prize on each paylines.

# Gameplay & Prize

## 《Pay Table》

More than 3 consecutive same symbols on a payline win the corresponding prize.

Symbol	3 on Paylines	4 on Paylines	5 on Paylines	All Same Prize
	1 x	10 x	30 x	7290 x
	0.8 x	6 x	25 x	6075 x
	0.6 x	5 x	20 x	4860 x
	0.4 x	4 x	16 x	3888 x
	0.2 x	2.4 x	10 x	2430 x
	0.08 x	0.6 x	1 x	243 x
	0.08 x	0.6 x	1 x	243 x
	0.08 x	0.6 x	1 x	243 x
	0.08 x	0.6 x	1 x	243 x
	0.08 x	0.6 x	1 x	243 x


# Gameplay & Prize

## ▶ Feature :

In Main Game		
Symbol		
Effect	Substitute for any other symbol except for Free Spin	3 or more this symbols in anywhere let you get free spin
Any 5	N/A	Free spin start with Maximum multiplier 3
Any 4	N/A	Free spin start with Maximum multiplier 2
Any 3	N/A	Free spin start with Maximum multiplier 1
In Free Spin		
Any 5	N/A	Free Spin +4
Any 4	N/A	Free Spin +3
Any 3	N/A	Free Spin +2
Any 2	N/A	Maximum multiplier may be increased
Any 1	N/A	Maximum multiplier may be increased

# Gameplay & Prize

## 《Free Spin》

3 or more  anywhere let you get free spin.

Number of  will effect the

Maximum multiplier of  in the free spin.



# Gameplay & Prize

## 《Double Up Game》

Any win in main game may enter Double Up Game by pressing **double up button**. Select Left or Right to specify your Red envelope.

If you choose the correct Red envelope, win **x2 bonus**.

If you choose the wrong Red envelope, win score become Zero and game over.

If you choose the correct Red envelope, there's a chance to win **x3~x5 bonus**.

If you choose the wrong Red envelope, God of Wealth may **give you one more chance**, continue the game.



# System Operation

## ▶ Parameter Adjust

In "**Parameter Adjust**" page, you can set game parameters including Game Difficulty / Coin Ratio / Key In Ratio / BGM, and etc.  
For parameter adjustment, password is necessary. ( **Default :0000000** )

Item	Default	Options
DP Game Difficulty	4	1,2,3,4
Coin Ratio A	50	1, 2, 3, 4, 5, 10, 20, 25, 30, 40, 50, 100, 200, 250, 300, 400, 500, 1000, 2000, 2500, 3000, 4000, 5000, 10000
Coin Ratio C	50	1, 2, 3, 4, 5, 10, 20, 25, 30, 40, 50, 100, 200, 250, 300, 400, 500, 1000, 2000, 2500, 3000, 4000, 5000, 10000
Key In Ratio B	10000	10, 20, 25, 30, 40, 50, 100, 200, 250, 300, 400, 500, 1000, 2000, 2500, 3000, 4000, 5000, 10000, 20000, 25000, 30000, 40000, 50000, 100000, 200000, 250000, 300000, 400000, 500000, 1000000
Key In Ratio D	10000	10, 20, 25, 30, 40, 50, 100, 200, 250, 300, 400, 500, 1000, 2000, 2500, 3000, 4000, 5000, 10000, 20000, 25000, 30000, 40000, 50000, 100000, 200000, 250000, 300000, 400000, 500000, 1000000
Key Out Ratio	10000	10, 20, 25, 30, 40, 50, 100, 200, 250, 300, 400, 500, 1000, 2000, 2500, 3000, 4000, 5000, 10000, 20000, 25000, 30000, 40000, 50000, 100000, 200000, 250000, 300000, 400000, 500000, 1000000
Credit Limit	100000	10000, 20000, 25000, 30000, 40000, 50000, 100000, 200000, 250000, 300000, 400000, 500000, 1000000, 2000000, 2500000, 3000000, 4000000, 5000000, 10000000, 20000000, 25000000, 30000000, 40000000, 50000000
System Limit	500000	10000, 20000, 25000, 30000, 40000, 50000, 100000, 200000, 250000, 300000, 400000, 500000, 1000000, 2000000, 2500000, 3000000, 4000000, 5000000, 10000000, 20000000, 25000000, 30000000, 40000000, 50000000, 90000000
Double up limit	50000	10000, 20000, 25000, 30000, 40000, 50000, 100000, 200000, 250000, 300000, 400000, 500000, 1000000, 2000000, 2500000, 3000000, 4000000, 5000000, 10000000
Withdraw Mode	Key Out (Coin)	Key Out (Coin), Key Out (Ticket)
Ticket Ratio	1/10	1/10000, 1/5000, 1/4000, 1/3000, 1/2500, 1/2000, 1/1000, 1/500, 1/400, 1/300, 1/250, 1/200, 1/100, 1/50, 1/40, 1/30, 1/25, 1/20, 1/10, 1/5, 1/4, 1/3, 1/2, 1, 2, 3, 4, 5, 10, 20, 25, 30, 40, 50, 100
Maximum Total-Bet	1000	100, 200, 250, 300, 400, 500, 1000, 2000, 2500, 3000, 4000, 5000, 6000, 7000, 8000, 9000
Minimum Total-Bet	200	100, 200, 250, 300, 400, 500, 1000, 2000
Bet increase rate	50	10, 20, 25, 30, 40, 50, 100, 200, 250, 300, 400, 500, 1000
Max Prize Max. Bet	500	100, 200, 250, 300, 400, 500, 600, 700, 800, 900, 1000, 2000, 2500, 3000, 4000, 5000, 6000, 7000, 8000, 9000
Award symbol setting	AKQJ10	Picture、AKQJ10
Residual Credit handling	Continue after adjustment	Continue after adjustment, Clear after time limit
DEMO BGM	On	On, Off
BGM	On	Off, On, SE, BGM
Volume	4	0, 1, 2, 3, 4, 5, 6, 7, 8
Reward Appearance	On	On, Off
System Time		
Change password		



# Connection Diagram

## ▶ 36 PIN

Parts Side	36PIN	36PIN	Solder Side
GND	[PA1]	[PB1]	GND
SPEAK ( L )	[PA2]	[PB2]	
SPEAK ( R )	[PA3]	[PB3]	
Stop1	[PA4]	[PB4]	
Stop2	[PA5]	[PB5]	
Stop3	[PA6]	[PB6]	
Stop4	[PA7]	[PB7]	
( Coin Box Sensor )	[PA8]	[PB8]	Coin-C
Start	[PA9]	[PB9]	
Stop5	[PA10]	[PB10]	
Auto	[PA11]	[PB11]	
Max Bet	[PA12]	[PB12]	
Help	[PA13]	[PB13]	
	[PA14]	[PB14]	
( Take Score )	[PA15]	[PB15]	
( Unuse)	[PA16]	[PB16]	
( Key In-D )	[PA17]	[PB17]	
Coin-A	[PA18]	[PB18]	Key In
	[PA19]	[PB19]	TKSW
Record	[PA20]	[PB20]	Test
Pay Out	[PA21]	[PB21]	Key Out
	[PA22]	[PB22]	HPSW
( Coin-C Meter )	[PA23]	[PB23]	Lamp: Grand Award
Key In Meter	[PA24]	[PB24]	Lamp: Pay Out Box
	[PA25]	[PB25]	Lamp: Error
( Coin-A Meter)	[PA26]	[PB26]	Lamp: Award
Pay Out Meter	[PA27]	[PB27]	
Key Out Meter	[PA28]	[PB28]	( Lamp: Unuse)
Lamp: Start	[PA29]	[PB29]	Lamp: Stop1
Lamp: Stop5	[PA30]	[PB30]	Lamp: Stop2
Lamp: Auto	[PA31]	[PB31]	Lamp: Stop3
Lamp: Max Bet	[PA32]	[PB32]	Lamp: Stop4
Lamp: Help	[PA33]	[PB33]	Lamp: Pay Out
( Lamp: Unuse)	[PA34]	[PB34]	( Lamp: Unuse)
	[PA35]	[PB35]	
GND	[PA36]	[PB36]	GND

# Connection Diagram

## ▶ 10 PIN

Parts Side	10PIN	10PIN	Solder Side
GND	[10P-A1]	[10P-B1]	GND
GND	[10P-A2]	[10P-B2]	GND
+ 5v	[10P-A3]	[10P-B2]	+ 5v
+ 5v	[10P-A4]	[10P-B4]	+ 5v
+ 12v	[10P-A5]	[10P-B5]	+ 12v
NC	[10P-A6]	[10P-B6]	NC
SSR-HP	[10P-A7]	[10P-B7]	SSR-TK
NC	[10P-A8]	[10P-B8]	NC
GND	[10P-A9]	[10P-B9]	GND
GND	[109-A10]	[10P-B10]	GND

## ▶ Control Panel



Button	1	2	3	4	5	6
Function	Pay Out	Help	(Unuse)	Auto	Max Bet	Start

Button	7	8	9	10	11	12
Function 1	Stop 1	Stop 2	Stop 3	Stop 4	Stop 5	Take Score
Function 2	Left	Right	Half DP	Double Up	Double DP	
Function 3	Bet	Line	Last Record			

# NOTE



Gong Xi  
Fa Cai

