

User's Manual

Game Description P.01 Operating Instructions P.03 System adjustment P.04 Cable definition P.06

Index

Game Description

☆[Game play instructions]

«Monkey King» Based on the marine fishing theme of the plane LCD monitor — lottery-type game, the game uses a high-definition screen design, support 4/6/8/10 while online games. 19 different types of fish, 10 kinds of powerful special Items, a clear definition and detailed undersea scene. It's the most popular game machine in your Game center.

☆[Game Features Description]

Special item—Floating in the field. Attack them to release special power!!

♦ Dragon Ball→	Randomly upgrade normal bullet to powerful Dragon Ball for free.
♦ Blasting Firecracker→	Cause Blasting Firecracker explode while de- feated. Attacking all fishes near exploding area.
♦ Ancient Cannon→	Cause Ancient Cannon explode while defeated. Killing all normal fish in the field at once.
Special Fish	
♦ Fish King →	Kill all same kind fishes in the field.
🔶 Treasure Dragonboat 🔿	Attack Treasure Dragonboat has a chance to
	drop random jewelry. Success break it will win
	high score award.
🔶 Pearl Roulette 🔿	Collect 5 corals drop form the Treas-
	ure Dragonboat will launch Pearl Roulette. Win
	the additional bonus scores.
🔶 Fiery Dragon 🔿	Get x500~800 randomly.
🔶 Golden Turtle 🔿	Get x200~500 randomly.
🔶 Silver Turtle 🔿	Get x100~200 randomly.
🔶 Monkey King 🔿	The Monkey King's Jingu Bang will fall into sea-
	bed,attack all fishes in the screen.



Game Description

☆[Odds Table]







☆[Operation Panel Instruction]



☆ 【Basic Operations 】

It' s easy to play!! After insert coins to credit, select your bet by Raise Bet button, aim your target by Direction Controller and SHOOT!!

Auto Attack→Press the "Shoot Button" 3 seconds to launch. Aim Attack → Press the direction controller "Down" for 3 seconds to launch. After launched, press "Up or Down" to select fish to aim.

🖈 [Play skills]

Use your special weapons well to win Huge score rewards. Select your launch timing, aim your target at fishes cluster.



System Adjustment


☆ [Parameter Adjust-Direct Adjust]

ltem	Default	Parameters				
itein	Delault					
Minimum Bet	50	1 , 2 , 5 , 10 , 20 , 30 , 40 , 50 , 100 , 200 , 250				
Maximum Bet	1000	10 , 20 , 30 , 40 , 50 , 100 , 200 , 500 , 1000				
Bet Increase Rate	10	1 , 2 , 5 , 10 , 20 , 50 , 100 , 200 , 500 , 1000				
Credit Limit	1000000	5000, 6000, 10000, 15000, 20000, 30000, 50000, 100000, 150000, 200000, 500000, 1000000, 2000000, 5000000, 10000000, 20000000, 50000000, 90000000				
System Limit	2000000	10000 , 15000 , 20000 , 30000 , 40000 , 50000 , 100000 , 150000 , 200000 , 300000 , 500000 , 1000000 , 2000000 , 5000000 , 10000000 , 20000000 , 50000000 , 90000000				
Ticket Ratio	1	1/100 , 1/80 , 1/50 , 1/25 , 1/15 , 1/10 , 1/08 , 1/5 , 1/4 , 1/3 , 1/2 , 1 , 2 , 3 , 4 , 5 , 8 , 10 , 15 , 20 , 25 , 50 , 80 , 100				
Withdraw Mode	KeyOut (Coin)	KeyOut(Coin) < KeyOut(Ticket) < AutoOut(Coin) < AutoOut(Ticket)				
Shooting Speed	Medium	Slow Medium Fast				
Bullet Speed	Medium	Slow Medium Fast				
AutoTrigger- Time	No	No 、Slow 、Medium 、Fast				
Auto shoot	On	Off、On				
Station Quan- tity	8(3-1)	2(2-0), 3(3-0), 4(2-2), 4(4- 0), 6(2-1), 8(2-2), 8(3-1), 8 (4-0), 8(8-0), 10(3-2)				
BGM	On	Off、On、SE、BGM				
Volume	4	0,1,2,3,4,5,6,7,8				
04						

System Adjustment

☆ [Parameter Adjust-Report Adjust]

ltem	Default	Parameters			
Coin Ratio	100	1 , 2 , 5 , 10 , 20 , 25 , 50 , 100 , 200 , 250 , 500 , 1000			
Key In Ratio	10000	100 , 200 , 250, 500 , 1000 , 2000 , 2500, 5000, 10000 , 20000 , 25000, 50000,100000			
Game Difficulty	5	0 , 1 , 2 , 3 , 4 ,5			
Location Scale	Medium Location	Small Location、Medium Location、Large Location			
Report Time period	10	1 ~ 30			
Profit Limit to Report	100000	10000 ~ 300000			
System Time		YYYY/MM/DD HH:MM:SS			
Change Pass- word	00000000				





Cable Definition

Up	1	2	Down
Left	3	4	Right
Raise bet	5	6	Shoot
Coin in	7	8	Key in
Key out	9	10	Pay out
Ticket SW	11	12	Hopper SW
Ticket SSR	13	14	Hopper SSR
Shoot lamp	15	16	Raise bet lamp
+12V	17	18	+12V
+12V	19	20	+12V
+5V	21	22	Ground
Ground	23	24	Ground
Ground	25	26	Ground















